Refrigerated Air Dryer

Series **IDFA E/F**

For use in Europe, Asia and Oceania

Standard/Series IDFA□E

●Power supply voltage: Single-phase 230 VAC (50Hz)

		Detect inter	Air flow c	apacity (m	h [ANR])	
	Model	Rated inlet condition	Outlet air	pressure of	dew point	Port size
		CONTUILION	3°C	7°C	10°C	
	IDFA3E		12.0	15.0	17.0	Rc 3/8
	IDFA4E		24.0	31.0	34.0	Rc 1/2
e	IDFA6E		36.0	46.0	50.0	
	IDFA8E		65.0	83.0	91.0	Rc 3/4
	IDFA11E	35°C	80.0	101.0	112.0	
	IDFA15E	0.7 MPa	120.0	152.0	168.0	Rc 1
4	IDFA22E		182.0	231.0	254.0	R 1
Ì	IDFA37E		273.0	347.0	382.0	R 1 1/2
	IDFA55E		390.0	432.0	510.0	5.0
	IDFA75F]	660.0	720.0	822.0	R2

Refrigerant R134a(HFC)

for ozone is zero.

AT

IDFA

IDFB

IDH

ID IDG **IDK AMG AFF** AM AMD **AMH** AME **AMF**

ZFC

SF

SFD

LLB

AD

GD

Improved corrosion resistance with the use of stainless steel, plate type heat exchanger (IDFA4E to 75E, 100F to 150F)



Large size/Series IDFA□F

●Power supply voltage: Three-phase 380 VAC (50Hz) For Asia and Oceania Three-phase 400 VAC (50Hz) For Europe

Tolerant of high temperature environment! Energy saving design

Top of its class in the industry for the large air-cooled type

Ambient temperature 45°C at max. Inlet air temperature 60°C at max.

Exhaust heat reduced by 25% at max. Ambient temperature increase suppressed. Employs a heat exchanger made of high corrosion-resistant stainless steel.



Refrigerant R407C(HFC

Coefficient of destruction fro ozone is zero.

Model	Rated inlet condition	Outlet air pressure dew point	Air flow capacity (m³/h [ANR])	Port size
IDFA100F-38	40°C 0.7 MPa		960	R 2
IDFA125F-38		10°C	1210	R 2 1/2
IDFA150F-38			1500	DIN flange 80
IDFA100F-40	35°C 0.7 MPa		860	R 2
IDFA125F-40		3°C	1100	R 2 1/2
IDFA150F-40	U.7 IVIFA		1340	DIN flange 80



69

INDEX

1. Standard Products Series IDFA□E



		Air flow o	anacity (m	3/h [ANR])			1
	Rated		. , .	,			
Model	inlet	Outlet air	pressure	dew point	Refrigerant	Port size	Page
	condition	3°C	7°C	10°C			
IDFA3E	35°C 0.7 MPa	12	15	17		Rc 3/8	
IDFA4E		24	31	34	R134a (HFC)	Rc 1/2	
IDFA6E		36	46	50		Rc 3/4 P. 72 to	D 70 to 74
IDFA8E		65	83	91			F. 72 to 74
IDFA11E		80	101	112			
IDFA15E		120	152	168		Rc 1	
IDFA22E		182	231	254		R 1	
IDFA37E		273	347	382	R407C (HFC)	R 1 ¹ / ₂	P. 75 to 77
IDFA55E		390	432	510	1 H4070 (HFC)		F. 13 (0 11
IDFA75E		660	720	822		R2	

2. Large size Series IDFA□F



Model	Rated inlet condition	Outlet air pressure dew point	Air flow capacity (m³/h [ANR])	Port size	Page
IDFA100F-38		40°C 0.7 MPa 10°C	960	R2	
IDFA125F-38			1210	R2 1/2	
IDFA150F-38	U.7 IVIFA		1500	DIN frange 80	P. 78 to 80
IDFA100F-40	35°C		860	R2	P. 70 10 00
IDFA125F-40	0.7 MPa		1100	R2 1/2	
IDFA150F-40			1340	DIN frange 80	

3. Options

o. Options			
Specifications	Applicable model	Suffix (Option symbol)	Page
Cool compressed air output	IDFA3E to 11E	IDFA□E-23-A	
Anti-corrosive treatment	IDFA3E to 75E	IDFA□E-23-C	
For medium air pressure (Up to 1.6 MPa) (Auto drain bowl type: Metal bowl with level gauge)	IDFA6E to 37E	IDFA□E-23-K	P. 81
With heavy duty auto drain (For medium air pressure)	IDFA4E to 75E	IDFA□E-23-L	
With circuit breaker	IDFA4E to 75E	IDFA□E-23-R	
With terminal block for power supply, run & alarm signal and remote operation	IDFA4E to 75E	IDFA□E-23-T	P. 82
Timer type solenoid valve with auto drain (Applicable to medium air pressure)	IDFA4E to 75E	IDFA□E-23-V	

4. Optional Accessories

Description	Page
Dust-protecting filter set	P. 83
Foundation bolt set	F. 63

SMC

Series IDFA□E Model Selection

The corrected air flow capacity, which considers the user's operating conditions, is required for selecting the air dryer. Please select using the following procedures.

However, for 400 VAC, model should also be selected based on the amount of processed air of 380 VAC regarding IDFA100F to 150F. (Correction factor is based on the rated conditions of 380 VAC, so when the factor of rated conditions of 400 VAC is inputted, the amount of processed air of 400 VAC can be found.)

1 Read the correction factor.

Obtain the correction factor A to D suitable for your operating condition using the table below.

IDFA□E Selection Example							
Condition Data symbol Correction factor Note)							
Inlet air temperature	40°C	Α	0.83				
Ambient temperature	35°C	В	0.83				
Inlet air pressure	0.5 MPa	С	0.92				
Air consumption	31 m ³ /h	_	_				

Note) Values obtained from the table below

2 Calculate the corrected air flow capacity.

Obtain the corrected air flow capacity from the following formula.

Corrected air flow capacity = Air consumption ÷ (Correction factor A x B x C)

Corrected air flow capacity = 31 m $^3/h$ \div (0.83 x 0.83 x 0.92) = 48.9 m $^3/h$

3 Select the model.

Select the model which air flow capacity exceeds the corrected air flow capacity using the specification table. (For air flow capacity, refer to the data D below.)

According to the corrected air flow capacity of 48.9 m³/h, the IDFA8E will be selected when the required output air pressure dew point is 3°C . The IDFA6E will be selected when the required pressure dew point is 10°C .

4. Option

31_.

Refer to pages 81 and 82.

5 Finalize the model number.

Refer to pages 72, 75 and 78.

6 Select accessories sold separately.

Refer to page 83.

Data A: Inlet Air Temperature

Inlet air temperature	Correcti	on factor	Inlet air temperature	Correction factor
(°C)	IDFA3E to 37E	IDFA55E to 75E	(°C)	IDFA100F to 150F
5 to 25	1.30	1.33	5 to 30	1.41
30	1.25	1.16	35	1.21
35	1	1	40	1
40	0.83	0.8	45	0.92
45	0.7	0.64	50	0.75
50	0.6	0.48	55	0.63
			60	0.53

Data B: Ambient Temperature

Ambient temperature	Correction	on factor	Ambient temperature	Correction factor
(°C)	IDFA3E to 11E	IDFA15E to 75E	(°C)	IDFA100F to 150F
20	1.1	1.1	2 to 25	1.06
25	1	1	30	1.02
30	0.91	0.97	32	1
35	0.83	0.89	35	0.99
40	0.79	0.77	40	0.98
			45	0.92

Data C: Inlet Air Pressure

Inlet air pressure	Correcti	on factor	Inlet air pressure	Correction factor
(MPa)	IDFA3E to 11E	IDFA15E to 75E	(MPa)	IDFA100F to 150F
0.3	0.80	0.72	0.2	0.84
0.4	0.87	0.81	0.3	0.87
0.5	0.92	0.88	0.4	0.9
0.6	0.96	0.95	0.5	0.93
0.7	1.00	1.00	0.6	0.96
0.8	1.04	1.06	0.7	1
0.9	1.07	1.11	0.8	1.03
1	1.1	1.16	0.9	1.06
1.2	1.16	1.21	1 to 1.6	1.09
1.4	1.21	1.25		
1.6	1.25	1.27		

Data D: Air Flow Capacity

Model		Air flow capacity (m ³ /h [ANR])							
		IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E			
Outlet air	3°C	12	24	36	65	80			
pressure	7°C	15	31	46	83	101			
dew point	10°C	17	34	50	91	112			

Note) In case of "Option A (Cool compressed air output)", the air flow capacity is different. Refer to page 81 for details.

Mode	Model			Air flow capacity (m ³ /h [ANR])			
IVIOUE	31	IDFA15E	IDFA22E	IDFA37E	IDFA55E	IDFA75E	
Outlet air	3°C	120	182	273	390	660	
pressure	7°C	152	231	347	432	720	
dew point	10°C	168	254	382	510	822	

Mode		Air	flow capacity (m3/h [AN	IR])
MODE	31	IDFA100F	IDFA125F	IDFA150F
Outlet air	3°C	670	860	1045
pressure	7°C	816	1029	1275
dew point	10°C	960	1210	1500

AD□ GD

HAW AT

IDF

IDFA

IDFB

IDH

ID

IDG

IDK

AMG

AFF

AM


AMD AMH

AME
ZFC
SF
SFD

Refrigerant R134a (HFC) Series IDFA E

3E, 4E, 6E, 8E, 11E, 15E (Inlet air temperature: 35°C)

How to Order



Options and Available Combinations (Size/Option)

Symbol Note 2)	Nil	Α	С	K	L	R	Т	٧
Option	None	Cool compressed air output	Anti- corrosive treatment	For medium air pressure (Auto drain bowl type: (Metal bowl with level gauge)	With heavy duty auto drain (Applicable to medium air pressure)	With circuit breaker	With terminal block for run & alarm signal	Timer type solenoid valve with auto drain (Applicable to medium air pressure)
3	•	•	•	_	_	_	_	
4	•	•	•	_	•	•	•	•
6	•	•	•	•	•	•	•	•
8	•	•	•	•	•	•	•	•
11	•	•	•	•	•	•	•	•
15	•	_	•	•	•	•	•	•

Note 1) G thread (PF thread) can accept the R thread (PT male thread), thus making no "F" in the thread specification setting.

A conversion adaptor for the R thread (PT male thread) is also contained.

Note 2) Enter alphabetically when multiple options are combined However, the following combination cannot be achieved.

Combination of K, L and V cannot be achieved because an auto drain can only be attached to a single option.

Note 3) Refer to pages 81 and 82 for further details on optional specifications



Refrigerated Air Dryer Series IDFA .

Standard Specifications



	Model Standard temperature air inlet											
	ecifications	8		IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E	IDFA15E			
Note 3)	Fluid			Compressed air								
range	Inlet air to	emperati	ure (°C)		5 to 50							
Operating range	Inlet air p	ressure	(MPa)	0.15 to 1.0								
Opera	Ambient	tempera	ture (Humidity) (°C)		2 to 40 (Relative humidity of 85% or less)							
		Note 1) Standard	Outlet air pressure dew point (3°C)	12	24	36	65	80	120			
_		condition	Outlet air pressure dew point (7°C)	15	31	46	83	101	152			
Note 4)	Air flow capacity	(ANR)	Outlet air pressure dew point (10°C)	17	34	50	91	112	168			
_su	m ³ /h	Com-Note 2)	Outlet air pressure dew point (3°C)	13	25	37	68	83	125			
atio		pressor intake	Outlet air pressure dew point (7°C)	16	32	48	86	105	158			
specifications		condition	Outlet air pressure dew point (10°C)	18	35	52	95	116	175			
gsp	Inlet air p	ressure	(MPa)	0.7								
Rated	Inlet air to	emperati	ure (°C)	35								
-	Ambient	tempera	ture (°C)			2	5					
	Power su	· · ·		Single	-phase: 23	VAC [Volt	age fluctua	ation ±10%]	50 Hz			
Electrical	Power co				180	385	470					
Elec	Operating	g current	t Note 6) (A)		1.2 1.4 2.7 3.							
	plicable ci ensitivity c		aker capacity Note 5) (A) 0 mA)			5			10			
č	ndenser					Air-co	ooled					
Re	frigerant					R134a	(HFC)					
Αι	ıto drain				Fle	oat type (No	ormally ope	en)				
Po	rt size			Rc 3/8	Rc 1/2		Rc 3/4		Rc 1			
Ac	cessory					Hexago	n nipple					
W	eight		(kg)	18	22	23	27	28	46			
Co	ating cold	or		Body panel: White 1 Base: Gray 2								
Co	mpliant s	tandards	3		EC [Directive (w	ith CE mar	king)				
Not	e 1) Air flow	capacity u	nder the standard condition (ANR) [atmos	pheric pressu	ure at 20°C, r	elative humi	dity at 65%]				

Refrigerated air dryer Auto drain

Symbol

Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure at 32°C, relative humidity at 75%].

Note 3) The operation range does not guarantee the use with normal air flow capacity. Note 4) Please select a model in accordance with the Model Selection (Page 71).

Note 5) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately

Note 6) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc.

Note 7) When a short-term interruption of the power supply (including momentary interruption) occurs in this equipment, the restarting of normal operations may require some time or may be impossible due to the operation of protective devices even after the supply of power returns.


	Replacement Parts						
1	Model	IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E	IDFA
1	Auto drain replacement part no. Note 8)	AD	38		Al		
8	The part number for the auto drain con Body part replacement is impossible.	nponents wi	ithout includ	ling the boo	dy part.	Body	

Construction Principle (Air/Refrigerant Circuit)


Note

Humid, hot air coming into the air dryer will be cooled down by a cooler re-heater (heat exchanger). Water condensed at this time will be removed from the air by auto drain and drained out automatically. Air separa-ted from the water will be heated by a cooler re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side





IDFA4E, IDFA6E IDFA8E, IDFA11E, IDFA15E



Auto drain

HAA HAW AT

IDF İĎŪ IDFA

IDFB

IDH ID

IDG IDK

AMG

AFF AM

AMD

AMH

AME

AMF

ZFC

SF

SFD


LLB


 $\mathsf{AD}\square$


Series **IDFA**□ **E**

Dimensions

IDFA3E to 15E







Dimension	ns													(mm)
Model	Port size	Α	В	С	D	Е	F	G	K*	L*	M*	N*	P	Q
IDFA3E	Rc 3/8	226	410	473	67	125	304	33	36	154	21	330		15
IDFA4E	Rc 1/2		453	498			283					275		13
IDFA6E		270	455	498	31	42	283	80		240	80	2/5	_	
IDFA8E	Rc 3/4	2/0	405	500	31	42	055	80	15	240	80	000		15
IDFA11E			485	568			355					300		
IDFA15E	Rc 1	300	603	578	41	54	396	87		43	101	380	314	16


^{*} Meaning the foot dimensions for the IDFA3E.

Refrigerant R407C (HFC) Series IDFA E

22E, 37E, 55E, 75E

(Inlet air temperature: 35°C)





Ontions and Available Combinations (Size/Ontion

			Options and A	valiable C	וווטוווטי	ลเเบเเอ (จ	Jize/Option)
Symbol Note 2)	Nil	С	K	L	R	Т	V
Option	None	Anti- corrosive treatment	For medium air pressure (Auto drain bowl type: (Metal bowl with level gauge)	With heavy duty auto drain (Applicable to medium air pressure)	With circuit breaker	With terminal block for run & alarm signal	Timer type solenoid valve with auto drain (Applicable to medium air pressure)
22	•	•	•	•	•	•	•
37	•	•	•	•	•	•	•
55	•	•	_	•	•	•	•
75	•	•	_	•	•	•	•

Note 1) G thread (PF thread) can accept the R thread (PT male thread), thus making no "F" in the thread specification setting.

Note 2) Enter alphabetically when multiple options are combined.

However, the following combination cannot be achieved.

Combination of K. L and V cannot be achieved because an auto drain can only be attached to a single

Note 3) Refer to pages 81 and 82 for further details on optional specifications

HAA HAW

AT

IDFA

IDFB IDH

ID

IDG IDK

AMG

AFF AM

AMD

AMH AME

AMF ZFC

SF

SFD

LLB AD□

Series IDFA E



Symbol Refrigerated i air dryer Auto drain

Standard Specifications

	_		N	Sta	andard temp	erature air ir	nlet				
Sp	ecifications	3		_	IDFA22E	IDFA37E	IDFA55E	IDFA75E			
Vote 3)	Fluid					Compre	ssed air				
auge	Inlet air t	emperatu	ire	(°C)		5 to 50					
Operating range	Inlet air p	ressure	(1	МРа)		0.15	to 1.0				
Opera	Ambient	temperat	ure (Humidity)	(°C)	2 to 40 (2 to 40 (Relative humidity of 85% or					
		Note 1)	Outlet air pressure dew point	(3°C)	182	273	390	660			
_		Standard condition	Outlet air pressure dew point	(7°C)	231	347	432	720			
lote 4	Air flow capacity	(ANR)	Outlet air pressure dew point	(10°C)	254	382	510	822			
us.	m ³ /h	Com-Note 2)	Outlet air pressure dew point	(3°C)	189	284	405	686			
Rated specifications Note 4)		pressor intake	Outlet air pressure dew point	(7°C)	240	361	449	748			
sciffe		condition	Outlet air pressure dew point	(10°C)	264	397	530	854			
ds p	Inlet air p	ressure	(1	МРа)	0.7						
3ate	Inlet air t	emperatu	ire	(°C)		35					
_	Ambient	temperat	ure	(°C)		2	5				
	Power su	pply volt	tage		Single-phase: 230 VAC [Voltage fluctuation ±10%] 50 Hz						
Electrical characteristics	Power co			(W)	760 1390 170						
Charac	Operating	g current	Note 6)	(A)	4	.3	6.1	7.9			
Αp	plicable ci	rcuit brea	aker capacity Note 5)	(A)		10		20			
Co	ndenser				Air-cooled						
Re	frigerant					R4070	(HFC)				
Αu	ıto drain						type lly open)				
Po	rt size				R 1	R 1 ¹ / ₂	R	2			
Accessory —											
We	eight			(kg)	54	62	100	116			
Cc	ating cold	or			Body panel: White 1 Base: Gray 2						
Co	mpliant s	tandards			EC Directive (with CE marking)						
Note	1) Air flow	canacity III	nder the standard cond	lition (ANR) [atmosni	neric nressure	at 20°C relati	ive humidity at			

- Note 1) Air flow capacity under the standard condition (ANR) [atmospheric pressure at 20°C, relative humidity at 65%]
- Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure at 32°C, relative humidity at 75%].
- Note 3) The operation range does not guarantee the use with normal air flow capacity.
- Note 4) When operating conditions are different from the rated specifications, please select a model in accordance with the Model Selection (Page 71).
- Note 5) Product other than the option R is not equipped with an earth leakage breaker. Please purchase an appropriate earth leakage breaker separately
- Note 6) These values are reference values under rated conditions, and are not guaranteed. Do not use these values for the thermal set values, etc
- Note 7) When a short-term interruption of the power supply (including momentary interruption) occurs in this

F	placement Parts	
	ration of protective devices even after the supply of power returns.	
	quipment, the restarting of normal operations may require some time or may be impossible due to the o	p-


IDFA22E | IDFA37E | IDFA55E | IDFA75E Model Auto drain replacement part no. Note 8) Note 8) The part number for the auto drain components without including the body part

Body part replacement is impossible.



Construction Principle (Air/Refrigerant Circuit)


Humid, hot air coming into the air dryer will be cooled down by a cooler re-heater (heat exchanger). Water condensed at this time will be removed from the air by auto drain and drained out automatically. Air separated from the water will be heated by a cooler re-heater (heat exchanger) to obtain the dried air, which goes through to the outlet side




Refrigerated Air Dryer $Series\ IDFA \square E$

Dimensions


IDFA22E, IDFA37E






Dimensio	ns													(mm	١
Model	Port size	Α	В	С	D	Е	F	G	K	L	M	N	Р	Q	
IDFA22E	R 1	290	775	623	404	405	000		13	25	0.5	600	340		
		290		023	134	405	698	93	13	25	85		340	_	

IDFA55E, IDFA75E





	Dimensior	Dimensions (mm)														
ĺ	Model	Port size	Α	В	С	D	E	F	G	K	L	М	N	Р	Q	R
	IDFA55E	R2	470	055	800	(100)	(070)	(868)	(110)	10	-00	75	700	-00	(440)	540
ľ	IDFA75E	H Z	470	855	900	(128)	(273)	(968)	(110)	13	500	75	700	526	(110)	519

HAA HAW

IDF IDU

IDFA IDFB

IDH

ID IDG

IDK AMG

AFF

AM

AMD AMH

AME

AMF ZFC

SF

SFD

LLB AD

Refrigerant R407C (HFC)


Series IDFA100F/125F/150F

For use in Europe, Asia and Oceania


(Max. inlet air temperature: 60°C, Max. ambient temperature: 45°C)

((

How to Order



Note) Enter alphabetically when multiple options are combined. Example: When the IDFA100F-38 is provided with options C or R or V, the model number will be the IDFA100F-38-CRV.



Note) Enter alphabetically when multiple options are combined Example: When the IDFA100F-40 is provided with options C or R or V, the model number will be the IDFA100F-40-CRV.

Refrigerated Air Dryer Series IDFA 100F/125F/150F

Standard Specifications





_		Model		in Asia and		For use in Europe				
Sp	ecifications		IDFA100F-38	IDFA125F-38	IDFA150F-38	IDFA100F-40	IDFA125F-40	IDFA150F-40		
ଅନ୍ତି	Fluid				Compre	ssed air				
1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Inlet air tempe	rature °C			5 to	60				
le e	Fluid Inlet air tempe Inlet air presso Ambient temperature	ure MPa		0.15	to 1.0/0.15 t	o 1.6 for opti	on K			
O E	Ambient temperature	(humidity) °C		2 to 45	(Relative hu	midity 85%	or less)			
	Air flow capacity	condition (ANR) Note 1)	960	1210	1500	860	1100	1340		
conditions	m³/h	Compressor intake Note 2) condition	1000	1255	1560	875	1119	1363		
8	Inlet air pressi	ure MPa		0.7						
Rated	Inlet air tempe	rature °C		40			35			
E E	Ambient temp			32			25			
	Outlet air pressure of	dew point °C		10		3				
tions	Power supply Power consum Operating curr	voltage	Thre	e-phase 380	VAC	Thre	e-phase 400	VAC		
cilica Cilica	Power consum	ption kW	2.8	3.4	3.4	2.5	2.7	2.7		
- ås	Operating curi	rent A	5.1	6.3	6.3	4.5	5.3	5.9		
Ap	pplicable circuit pacity Note 4)	breaker A	15							
	eat discharge fro Indenser	m kW	7.5	9	11.5	7	8	10		
Re	efrigerant				R407C	(HFC)				
Αι	uto drain		Т		loat type (No stands for a).		
Po	ort size		R2	R2 1/2	DIN flange 80	R2	R2 1/2	DIN flange 80		
W	eight	kg	245	270	350	245	270	350		
C	oating color		Body panel: White 1 Base: Gray 2							
_	ompliant standa				ctive complia					

Note 1) Air flow capacity under the standard condition (ANR) [atmospheric pressure 20°C, relative humidity 65%] Note 2) Air flow capacity converted by the compressor intake condition [atmospheric pressure 32°C]

Note 3) The operation range does not guarantee the use with normal air flow capacity. When operating conditions are different from the rated specifications, please select a model in accordance with Model Selection (page 71). Note 4) Install a circuit breaker with a sensitivity 30 mA.

Replacement Parts

Air dryer model	IDFA100F	IDFA125F	IDFA150F	
Heavy duty auto drain replacement part no. Note 5)		ADH-E400		
Dustproof filter set for condenser	IDF-FL219 IDF-F			

Note 5) Part number of only the exhaust mechanism replacement kit excluding the housing






Refrigerated

Symbol

Construction (Air/Refrigerant Circuit)

Hot and humid air entering the air dryer is cooled down by the cooler re-heater (heat exchanger). The moisture which is condensed and separated is automatically exhausted by the auto drain. The air which has had its moisture removed is heated in two stages by the re-heater (heat exchanger) in the cooler re-heater and by the secondary heater, and is supplied to the outlet side as warm and dry air.

IDFA100F/125F/150F



Secondary heater

Compressed air from which drainage has been exhausted exchanges heat with refrigerant which has been compressed by the refrigerator, to give the following effects:

- The outlet air temperature increases, preventing condensation of the piping on the outlet side.
- 2. The amount of heat exhausted from the condenser is
- 3. Energy saving operation of the dryer is achieved by reducing the amount of heat exhausted from the condenser.

SMC

79

HAA HAW

IDF IDU

IDFB

ID IDG

IDK AMG

AFF

AMD

AMH

AME

AMF

ZFC SF


SFD

LLB AD

Series IDFA100F/125F/150F

Dimensions


IDFA100F/125F



Note) In addition to the overall length of the body, the filter mounting part (bracket) projects 10 mm.

Dimension	าร												(mm)
Model	Port size	Α	В	С	D	E	F	G	K	L	M	N	P
IDFA100F	R2	670	1120	1100 1070	1276 267	460	1375	335	20	712	107	700	752
IDFA125F	R2 1/2	700	1120	12/6	207	655	13/5	350	20	/12	78	935	/52

IDFA150F



Note) In addition to the overall length of the body, the filter mounting part (bracket) projects 10 mm.

Di	Dimensions (mm)													
	Model	Port size	Α	В	С	D	E	F	G	K	L	M	N	P
11	DFA150F	DIN flange 80	950	1290	1332	268	720	1432	475	20	990	217	935	1030

Series IDFA□E/F Options 1

For "How to Order" optional models, refer to pages 72, 75 and 78.

A Option symbol Cool compressed air output IDFA3E to 11E

There is no heating of cooled, dehumidified air as it leaves the air dryer. The air flow capacity with this option is smaller than that of the standard dryer. (The external dimensions are identical with the standard product.) Note) Perform thermal insulation treatment for piping and equipment installed after the dryer to prevent the formation of condensation.

Air Flow Capacity

Model	IDFA3E	IDFA4E	IDFA6E	IDFA8E	IDFA11E
Air flow capacity m3/h (ANR)	8	23	29	32	39

Conditions: Inlet air pressure: 0.7 MPa, Inlet air temperature: 35°C ,
Outlet air temperature: 10°C Ambient temperature: 25°C

Option symbol

Anti-corrosive treatment IDFA all models

This minimizes the corrosion of the copper and copper alloy parts when the air dryer is used in an atmosphere containing hydrogen sulfide or suliurous acid gas. (Corrosion cannot be completely prevented.) Special epoxy coating: Copper tube and copper alloy parts.

The coating is not applied on the heat exchanger or around electrical parts, where operation may be affected by the coating.

Corrosion is not covered under warranty.

Option symbol

Moderate pressure specification
(Auto drain bowl type:
(Metal bowl with level gauge)

IDFA6E to 37E

The auto drain is changed from the standard one to one with a moderate pressure specification.

A metal bowl with a level gauge which can confirm the water level is used for the auto drain.

Specifications

- Maximum operating pressure: 1.6 MPa
- 2. Dimensions ... same as standard products

Replacement Parts

Model Auto drain assembly part r		Note
IDFA6E to 15E	IDF-S0086	The AD48-8-X2110 auto drain, insulator, and One-touch fitting are included.
IDFA22E, 37E	AD48-8-X2110	Single auto drain unit



The maximum operating pressure is 1.6 MPa.
The internal drain piping material is changed from nylon to metal.

Specifications


- Maximum operating pressure: 1.6 MPa
- 2. Dimensions --- same as standard products

Option symbol With heavy duty auto drain (Applicable to moderate air pressure) IDFA4E to 75E


The float type auto drain used in the standard air dryer is replaced with a heavy duty auto drain (ADH4000-04) which enables the drainage to discharge more efficiently.

IDFA4E to 15E

Dimensions	(mm)
Model	Α
IDFA4E	55
IDFA6E	67
IDFA8E, 11E	139
IDFA15E	47
7	



IDFA22E to 75E



Note 1) The heavy duty auto drain and the ball valve are both enclosed in the same shipping package as the main body of the air dryer. Customers are required to mount the parts to the air dryer, (Except IDFA22E to 75E)

Note 2) Customers will need to supply the fitting and tubing for the drain piping. (Except IDFA22E to 75E)

Replacement Parts: Heavy Duty Auto Drain

Replacement Parts: Heavy Duty Auto Drain								
Model	Replacement part no. (Description)	Configuration						
IDFA4E to 15E	ADH4000-04 (Heavy duty auto drain)	Heavy duty auto drain						
IDFA22E to 75E	ADH-E400 (Replacement kit for exhaust mechanism)	Replacement kit for exhaust mechanism						
		(You don't need to purchase a new housing.)						

AT IDF IDU

IDFA IDFB

IDH ID

IDG IDK

AMG AFF

AM

AMH AME

AMF


ZFC SF

SFD

LLB AD□

Series IDFA□E/F Options 2


For "How to Order" optional models, refer to page 72, 75 and 78.



IDFA4E to 75E, IDFA100F to 150F


A circuit breaker with cover is attached to the side of the air dryer. This saves additional electrical wiring at the time of installation.

IDFA4E to 15E




Dimensions (mm									
Model	Α	В	С	D	E				
IDFA4E, 6E, 8E, 11E	32	230	97	34	15				
IDFA15E	43	258	102	82	_				

IDFA22E to 75E



Dimensions (mm)										
Model	Α	В	С	D	E	F				
IDFA22E	405	59		40	25	46				
IDFA37E	125	39	60			46				
IDFA55E	148	81	60	60	50	36				
IDFA75E	133	73		60	30	30				

IDF100F to 150F



Dimensions		(mm)
Model	Α	В
IDFA100F	509	535
IDFA125F	505	333
IDFA150F	628	537

Breaker Capacity and Sensitivity Current

Voltage	Model	Breaker capacity	Sensitivity current
230 V type	IDFA4E-23, IDFA6E-23 IDFA8E-23, IDFA11E-23	5 A	
	IDFA15E-23, IDFA22E-23 IDFA37E-23, IDFA55E-23	10 A	30 mA
	IDFA75E-23	20 A	
380/400 V type	IDFA100F, IDFA125F IDFA150F	15 A	

Option symbol

With terminal block for power supply, run & alarm signal and remote operation

IDFA4E to 75E


In addition to the terminals for the power supply, terminals for the operating signal and the error signal are also available. (No-voltage contact) Also, in the case of remote control, operate it from the power supply side while the air dryer switch remains ON.

Contact capacity: 230 VAC, 4 A 24 VDC, 5 A for operating and error signals.

Minimum current value: 20 V, 5 mA (AC/DC) for operating and error signals.


Note 1) Terminal block for power supply, run & alarm signal and remote operation is mounted on the standard types of the IDFA100F to 150F.

Note 2) Please be sure to confirm the electric circuits with the drawings or instruction manual before using the output signal.



Dimensions (mm)									
Model	Α	В	С	D					
IDFA4E, 6E, 8E, 11E	32	230	67	179					
IDFA15E	43	258	77	158					

IDFA22E to 75E



Dimensions (mm)										
Model	Α	В	С	D						
IDFA22E, 37E	25	46	135	81						
IDFA55E, 75E	50	36	207	81						

Option syr

Timer type solenoid valve with auto drain (Applicable to medium air pressure)

IDFA4E to 75E IDFA100F to 150F

Drainage is discharged by controlling a solenoid valve with a timer. A strainer for solenoid valve protection and stop valve are also included. (Dimensions are the same as the standard type.)

Maximum operating pressure: 1.6 MPa (IDFA100F to 150F: 1.0 MPa)

* The timer-type solenoid valve actuates once (for 0.5 s) every 30 s.

Replacement Parts

. iopiacoment i arte						
	Model	Part no.	Note			
	IDFA4E to 37E	IDF-S0198	230 VAC			
	IDFA55E, 75E	IDF-S0302	230 VAC			
	IDFA100F to 150F	IDF-S0405	200 VAC			

Series IDFA□E/F Optional Accessories

		Features	Specifications	Applicable dryer	
Dust-protecting filter set		Prevents a decline in the performance of the air dryer, even in a dusty atmosphere.	Max. ambient temperature 40°C	IDFA3E to 75E	
Foundation bolt set	No.	Bolts for fixing the air dryer to the foundations. Easy to secure by striking its axle.	Stainless steel	IDFA4E to 75E IDFA100F to 150F	

How to Order

Dust-protecting filter set

Applicable dryer •				
Symbol	Applicable dryer			
209	IDFA3E			
202	IDFA4E			
203	IDFA6E			
204	IDFA8E			
205	IDFA11E			
206	IDFA15E			
207	IDFA22E			
208	IDFA37E			
213	IDFA55E			
214	IDFA75E			

Foundation bolt set

IDF-AB 500

Applicable dryer


	Symbol	Applicable dryer	
	500	IDFA4E to 75E	
	501	IDFA100F to 150F	

Dust-protecting Filter Set/Dimensions



(IDF-FL209)





		•				
/IDE	-1	202	٠.	200	212	21

Dimensions						
Part no.	Applicable dryer	Α	В	Weight (g)		
IDF-FL209	IDFA3E	220	240	35		
IDF-FL202	IDFA4E	310	405	45		
IDF-FL203	IDFA6E	375	195	55		
IDF-FL204	IDFA8E	340	265	70		
IDF-FL205	IDFA11E	375	205	75		
IDF-FL206	IDFA15E	440	370	120		
IDF-FL207	IDFA22E	420	315	100		
IDF-FL208	IDFA37E	550	365	140		
IDF-FL213	IDFA55E	720	400	175		
IDF-FL214	IDFA75E	610	560	190		

HAA HAW AT IDF İĎŪ

IDFA

IDFB

IDH

ID IDG IDK AMG AFF AM AMD

AMH AME AMF ZFC

SF SFD


LLB

 $\mathsf{AD}\square$

GD

83

Foundation Bolt Set/Dimensions



Dimensions							
Part no.	Applicable dryer	Nominal thread size	Material	Pcs. of 1 set			
IDF-AB500	IDFA4E to 75E	M10	Stainless steel	4			
IDF-AB501	IDFA100F to 150F	IVITO	Stamless steel	4			




Series IDFA□E/F Specific Product Precautions 1

Be sure to read before handling.

Refer to front matter 43 for Safety Instructions and pages 6 to 8 for Air Preparation Equipment Precautions.

Installation

- Avoid locations where the air dryer will be in direct contact with wind and rain. (Places where relative humidity is greater than 85%)
- Avoid exposure to direct sunlight.
- Avoid locations that contain much dust, corrosive gases, or flammable gases. Failure due to corrosion is not covered under warranty. However, when the risk of corrosion is high, select "Option C" (copper tubing with anti-corrosive treatment).
- Avoid locations of poor ventilation and high temperature.
- Avoid too close to a wall etc. Leave sufficient room between the dryer and the wall according to the "Maintenance space" in the operation manual.
- Avoid locations where a dryer could draw in high temperature air that is discharged from an air compressor or other dryer.



The air exhaust should not flow into the neighboring equipment. (Top side)

- · Avoid locations subjected to vibration.
- · Avoid possible locations where the drain can freeze
- Use the air dryer with an ambient temperature lower than 40°C.
- Avoid installation on machines for transporting, such as trucks, ships, etc.

Drain Tube

⚠ Caution

- A polyurethane tube is attached as a drain tube for the IDFA3E to 75E and IDFA100F to 150F. Use this tube to discharge drainage.
- Do not use the drain tube in an upward direction. Do not bend or crush the drain tube. (Operation of the auto drain will stop water vapor from discharging through the air outlet.)
- If it is unavoidable that the tube goes upwards, make sure it only goes as far as the position of the auto drain.

Power Supply

♠ Caution

- · Connect the power supply to the terminal block.
- Install a suitable circuit breaker applicable for the specific model.
- The voltage fluctuation should be maintained within $\pm 10\%$ of the rated voltage.


Note) Select a circuit breaker with a sensitivity current 30 mA. As regards rated current, refer to "Applicable circuit breaker capacity" on pages 73, 76 and 79.

Air Piping


∕ Caution


- Be careful to avoid an error in connecting the air piping at the compressed air inlet (IN) and outlet (OUT).
- Install by-pass piping since it is needed for maintenance.

IDFA3E Compressed air inlet Compre



IDFA4E to 15E










Series IDFA□E/F Specific Product Precautions 2

Be sure to read before handling.

Refer to front matter 43 for Safety Instructions and pages 6 to 8 for Air Preparation Equipment Precautions.

Air Piping



- When tightening piping at the air inlet/outlet tube, the hexagonal parts of the port on the air dryer side or piping should be held firmly with a spanner or adjustable angle wrench.
- Variations in operating conditions may cause condensation to form at the surface of the outlet piping. Apply thermal insulation around the piping to prevent condensation from forming.
- Vibration resulting from the compressor should not be transmitted through air piping to the air dryer.
- Do not allow the weight of the piping to lie directly on the air dryer.

Protection Circuit

When the air dryer is operated under the following stated conditions, a protection circuit is activated, the light turns off and operation stops.

- When the compressed air temperature is too high.
- When the compressed air flow rate is too high.
- When the ambient temperature is too high. (40°C or higher, however, 45°C or higher for IDFA100F to 150F)
- When the fluctuation of the power supply is beyond the rated voltage ±10%.
- When the dryer is drawing in high temperature air that is discharged from an air compressor or other dryer.
- The ventilation port is obstructed by a wall or clogged with dust.

Compressor Air Delivery

↑ Caution

Use an air compressor with an air delivery of 100 L/min or larger with the IDFA3E to 75E series.

Since the auto drain of the IDFA3E to 75E is designed in such a way that the valve remains open unless the air pressure rises to 0.15 MPa or higher (0.05 MPa or more for IDFA100F to 150F), air will blow out from the drain discharge port at the time of air compressor start-up until the pressure increases. Therefore, if an air compressor has a small air delivery, the pressure may not be sufficient.

Auto Drain

The auto drain may not function properly, depending on the quality of the compressed air. Check the operation once a day.

Cleaning of Ventilation Area

Remove dust from the ventilation area once a month using a vacuum cleaner or an air blow nozzle.

Time Delay for Restarting

⚠ Caution

Allow at least three minutes before restarting the dryer. If the air dryer is restarted within three minutes after being stopped, the protection circuit will be activated, operating light turns off and the dryer will not be activated.

Modifying the Standard Specifications

⚠ Caution

Do not modify the standard product using any of the optional specifications once the product has been supplied to a customer. Check the specifications carefully before selecting an air dryer.

HAA HAW

AT

IDFA IDFB

IDH

ID IDG

IDK

AMG AFF

AM

AMD AMH

AME

ZFC

SF SFD

LLB

AD GD